


MonoFlat LIN-X hinge TM

MonoFlat LIN-X 450 Instruction Manual

Thank you for purchasing this MonoFlat LIN-X hinge by SUGATSUNE. Before proceeding with the installation, please read this instruction manual carefully for the best possible result and ensure your safety.




WARNING

- Failure to observe the following precautions may result in injury and/or lead to damage to surrounding cabinets or fittings.
- Choose suitable screws to ensure of proper installation of the cabinet and door.
- Ensure that door size, weight and material correspond to the specifications stated in this manual.
- Do not disassemble or modify the system.


■ Product Specification

Door width	400 ~ 500 mm
Door height	600 ~ 900 mm
Door thickness	15 ~ 24 mm
Door weight	Max 7 kg (per door)

■Parts List




- ■Overall (unit: mm)
 - Picture shows the left hand door use. (Right hand door use is symmetrical.)




■Overlay distance


- Side overlay as shown in Fig. 1 is:
 - 1 9 mm for mounting plate 230-P4W-32T
 - 1 4 mm for mounting plate 230-P4W-32T+5
- An opening clearance of 2mm is required on both sides of the door.



■Position of LIN-X Body

• Prepare the door as per Fig. 2 and Fig. 3





■Mounting Plate Position

 Prepare the sideboard for mounting plate installation as Fig. 4








Fig.4


■Installation


1 Mounting plate installation:




2 Cup Cover installation:











Ensure that the two LIN-X bodies are parallel by measuring both the base and mounting plate distances.



5 Door installation:




Ensure that the LIN-X body is securely attached to the mounting plates.



Adjustments

Adjustment screw (Horizontal)

Turn screw to adjust.




Adjustment screw (Depth)


Loosen screw, adjust the door and retighten screw.



Loosen screw, adjust the door and retighten screw.





Leveling Adjustment Screw Front



Loosen both screws, adjust the door







Back

SUGATSUNE KOGYO (UK) LTD

Reading, UK
Phone: +44 118 9272 955 E-mail:sales@sugatsune.co.uk

SUGATSUNE EUROPE GmbH

Düsseldorf, GERMANY
Phone: +49 211 53812900 E-mail:sales@sugatsune.eu
ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

E-mail:lamp@sugatsune.com.cn

Guangzhou, CHINA

E-mail:lamp@sugatsune.com.cn Phone: +86 20 6639 3552

SUGATSUNE KOGYO INDIA PRIVATE LIMITED

Chicago, USA

Phone: +1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com.

SUGATSUNE CANADA, INC.

Phone: +1 514 312 5267 E-mail:support@sugatsune.ca

2017.09 0445-2